



ASSEMBLY INSTRUCTION CORTEZ BUFFET BLACK

Pre Assembly:


- Please read all instructions before beginning assembly
- Place all parts on a carpet or foam in shipping box.
 Find the letter (A, B, C,...) on each part and check with below part list to ensure we have all components.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- This product requires two people to do assembly.




Parts Included:



C Anti-Tip - 2 pcs	D - EZ Anchor - 4pcs	E - Srew Ø5 * 40 - 4pcs	F - Srew Ø3 * 15 - 4pcs
	(2000 and 1000 and 10	*VIIIIIV	*\nnn
G - Bolt Ø6*30-12 pcs	H - Washer 1*Ø6 * 13 - 12pcs	I - Washer 1*Ø6 * 11 - 12pcs	J Allen Key- 1pc
(a)			





Care Instructions:


- Hardware may loosen overtime. Periodically check to make sure all components are tight. Re-tighten if necessary.
- Should clean dust with soft dry cloth
- For indoor use only




ASSEMBLY INSTRUCTION CORTEZ DINING TABLE 220 BLACK

Pre Assembly:


- Please read all instructions before beginning assembly
- Place all parts on a carpet or foam in shipping box.
 Find the letter (A, B, C,...) on each part and check with below part list to ensure we have all components.
- Save all packing materials until assembly is complete to avoid accidentally discarding smaller parts or hardware.
- This product requires two people to do assembly.




Parts Included:



C - Bolt - Ø8*35 -12 pcs	D - Washer 1*Ø8 * 16 - 12pcs	E - Washer 1*Ø8 * 13 - 12pcs	E -Allen Key - 1pc





Care Instructions:

- Hardware may loosen overtime. Periodically check to make sure all components are tight. Re-tighten if necessary.
- Should clean dust with soft dry cloth
- For indoor use only