


ASSEMBLY INSTRUCTION

VLD09 - DINING TABLE 180

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.





ASSEMBLY INSTRUCTION :




1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly




WARNING !


1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time : 1/2 hours.
5. Component parts and fittings contained in the box.
Please sort out all parts before you begin to assemble the item.
This is to make sure you always use the correct part .
6. It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product .
Toppling furniture can cause serious injuries and death.
This product has not been fitted with an anchor strap.
To prevent your furniture from tipping forward it is strongly recommended
that you securely attach this product to a wall or other solid surface, using the anchor straps
provided and appropriate fixings.

No.	Component	Q'ty
Ⓐ	 Top panel	1
Ⓑ	 Leg frames	2


No.	Hardware list	Q'ty
①	 Bolts M10x60	12
②	 Flat washers Ø10x20	12
③	 Lock washers Ø10x14	12

No.	Hardware list	Q'ty
④	 Wrench K17	1


Step 1



Step 2



Step 3




Finish

ASSEMBLY INSTRUCTION

VLD73 - MEDIUM BUFFET

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.





ASSEMBLY INSTRUCTION :



1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly




WARNING !



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time : 1/2 hours.
5. Component parts and fittings contained in the box.
Please sort out all parts before you begin to assemble the item.
This is to make sure you always use the correct part .
6. It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product .
Toppling furniture can cause serious injuries and death.
This product has not been fitted with an anchor strap.
To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wall or other solid surface, using the anchor straps provided and appropriate fixings.

No.	Hardware list	Q'ty
①	 Anti-tip kit	2
②	 Screw M4 x 20	4

No.	Hardware list	Q'ty
③	 Screw M4 x 35	4
④	 Wall plug	4




Step 1



ASSEMBLY INSTRUCTION

VLL09 - SMALL TV UNIT

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.





ASSEMBLY INSTRUCTION :



1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly




WARNING !



1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time : 1/2 hours.
5. Component parts and fittings contained in the box.
Please sort out all parts before you begin to assemble the item.
This is to make sure you always use the correct part .
6. It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product .
Toppling furniture can cause serious injuries and death.
This product has not been fitted with an anchor strap.
To prevent your furniture from tipping forward it is strongly recommended that you securely attach this product to a wall or other solid surface, using the anchor straps provided and appropriate fixings.

No.	Hardware list	Q'ty
①	 Anti-tip kit	2
②	 Screw M4 x 20	4

No.	Hardware list	Q'ty
③	 Screw M4 x 35	4
④	 Wall plug	4



Step 1



ASSEMBLY INSTRUCTION

VLL13 - LARGE TV UNIT

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside carton during shipment. Identify and count all parts and compare with the parts list below.


ASSEMBLY INSTRUCTION :



1. Remove hardware from box and sort by size.
2. Please check to see that all hardware and parts are present prior start of assembly.
3. Please follow attached instruction in the same sequence as numbered to assure fast and easy assembly





WARNING !

1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishments.
3. Two persons are required for assembly.
4. Approximate assembly time : 1/2 hours.
5. Component parts and fittings contained in the box.
Please sort out all parts before you begin to assemble the item.
This is to make sure you always use the correct part .
6. It is **STRONGLY RECOMMENDED** that you **ANCHOR** this product .
Toppling furniture can cause serious injuries and death.
This product has not been fitted with an anchor strap.
To prevent your furniture from tipping forward it is strongly recommended
that you securely attach this product to a wall or other solid surface, using the anchor straps
provided and appropriate fixings.



No.	Hardware list	Q'ty
①	 Anti-tip kit	2
②	 Screw M4 x 20	4

No.	Hardware list	Q'ty
③	 Screw M4 x 35	4
④	 Wall plug	4

Step 1

